



DOWN DIRECTION

ASPECT SEQUENCE CHART			
DN DIST.	DN HOME S 2	DN MAIN STG. S 3	DN ADV STG. S 8
G	G	G	G
YY	YU*	Y	R
Y	R	R	Y

* YELLOW WITH ROUTE.

SPARE NOS. :-
 SIGNALS (S1 TO S20) :- S1, S7, S8, S11, S12, S13, S16.
 POINTS (101 TO 115) :- 105, 106, 107, 108, 109, 110, 111, 112.
 TRACKS (201 TO 250) :- 205T, 206T, 207T, 212T, 213T, 214T, 215T, 221T, 222T, 223T, 224T, 225T, 230T, 231T, 232T, 233T, 235T, 236T, 242T, 243T, 244T, 245T.

UP DIRECTION

ASPECT SEQUENCE CHART			
UP ADV. STG. S 15	UP MAIN STG. S 19	UP HOME SIG S 20	UP DIST. S 8
G	G	G	G
R	Y	YU*	YY
Y	R	R	Y

* YELLOW WITH ROUTE.

SIGNAL & TELECOMMUNICATIONS
 lapkyu fu; e vkjz[k
 dse
KEM (B.G)
 * [k * Jg.kh] ekud AA ¼vkjz[k CLASS, STD. 11 (R)
 C.RLY, SUR. DIV. NOT TO SCALE
 BASED ON C. RLY. DRG. S.I.P. No.-6211/01/A